

Approval body for construction products
and types of construction

Bautechnisches Prüfamt

An institution established by the Federal and
Laender Governments



European Technical Assessment

ETA-19/0501
of 30 October 2019

English translation prepared by DIBt - Original version in German language

General Part

Technical Assessment Body issuing the
European Technical Assessment:

Deutsches Institut für Bautechnik

Trade name of the construction product

fischer Superbond dynamic

Product family
to which the construction product belongs

Bonded anchor for use in concrete
under fatigue cyclic loading

Manufacturer

fischerwerke GmbH & Co. KG
Otto-Hahn-Straße 15
79211 Denzlingen
DEUTSCHLAND

Manufacturing plant

fischerwerke

This European Technical Assessment
contains

25 pages including 3 annexes which form an integral part
of this assessment

This European Technical Assessment is
issued in accordance with Regulation (EU)
No 305/2011, on the basis of

EAD 330250-00-0601

The European Technical Assessment is issued by the Technical Assessment Body in its official language. Translations of this European Technical Assessment in other languages shall fully correspond to the original issued document and shall be identified as such.

Communication of this European Technical Assessment, including transmission by electronic means, shall be in full. However, partial reproduction may only be made with the written consent of the issuing Technical Assessment Body. Any partial reproduction shall be identified as such.

This European Technical Assessment may be withdrawn by the issuing Technical Assessment Body, in particular pursuant to information by the Commission in accordance with Article 25(3) of Regulation (EU) No 305/2011.

Specific Part

1 Technical description of the product

The injection system fischer superbond dynamic is a bonded anchor consisting of a cartridge with injection mortar FIS SB or FIS SB High Speed or mortar capsule RSB, an anchor rod FIS A or RG M, a centering sleeve (only for through-setting installation), a conical washer with bore, a hexagon nut with spherical contact surface and a locknut. Alternatively the hexagon nut with spherical contact surface can be replaced by a spherical disc with hexagon nut.

The steel element is placed into a drilled hole filled with injection mortar and is anchored via the bond between metal part, injection mortar and concrete.

The resin capsule is placed into the hole and the steel element is driven by machine with simultaneous hammering and turning. The anchor rod is anchored via the bond between steel element, chemical mortar and concrete.

The product description is given in Annex A.

2 Specification of the intended use in accordance with the applicable European Assessment Document

The performances given in Section 3 are only valid if the anchor is used in compliance with the specifications and conditions given in Annex B.

The verifications and assessment methods on which this European Technical Assessment is based lead to the assumption of a working life of the anchor of at least 50 years. The indications given on the working life cannot be interpreted as a guarantee given by the producer, but are to be regarded only as a means for choosing the right products in relation to the expected economically reasonable working life of the works.

3 Performance of the product and references to the methods used for its assessment

3.1 Mechanical resistance and stability (BWR 1)

Essential characteristic	Performance
Characteristic fatigue resistance under cyclic tension loading (Assessment method C)	
Characteristic steel fatigue resistance	See Annexes C1 and C3
Characteristic concrete cone and splitting fatigue resistance	
Characteristic combined pull- out /concrete cone fatigue resistance	
Characteristic fatigue resistance under cyclic shear loading (Assessment method C)	
Characteristic steel fatigue resistance	See Annexes C2 and C3
Characteristic concrete edge fatigue resistance	
Characteristic concrete pry out fatigue resistance	

Essential characteristic	Performance
Characteristic fatigue resistance under cyclic combined tension and shear loading (Assessment method C)	
Characteristic steel fatigue resistance	See Annexes C2 and C3
Load transfer factor for cyclic tension and shear loading	
Load transfer factor	See Annexes C2 and C3

4 Assessment and verification of constancy of performance (AVCP) system applied, with reference to its legal base

In accordance with European Assessment Document No. 330250-00-0601, the applicable European legal act is: [96/582/EC].

The system to be applied is: 1

5 Technical details necessary for the implementation of the AVCP system, as provided for in the applicable European Assessment Document

Technical details necessary for the implementation of the AVCP system are laid down in the control plan deposited with Deutsches Institut für Bautechnik.

Issued in Berlin on 30 October 2019 by Deutsches Institut für Bautechnik


Dr.-Ing. Lars Eckfeldt
p. p. Head of Department

beglaubigt:
Stiller


Installation conditions

fischer anchor rod FIS A or RG M with fischer injection system FIS SB

Pre positioned installation with the necessary components (annular gap filled with mortar)




Push through installation with the necessary components (annular gap filled with mortar)



fischer anchor rod RG M with fischer mortar capsule system RSB

Pre-positioned installation with the necessary components (annular gap filled with mortar)



Figures not to scale


fischer Superbond dynamic

Product description
Installation conditions


Annex A 1

Overview system components Part 1

Mortar cartridge (shuttle cartridge) with sealing cap; Size: 390 ml, 585 ml, 1100 ml, 1500 ml



Mortar cartridge (coaxial cartridge) with sealing cap; Size: 150 ml, 300 ml, 380 ml, 410 ml




Mortar capsule


Size: 12 mini, 12, 16 mini, 16



Static mixer FIS MR Plus or UMR



Injection adapter / extension tube for static mixer



Figures not to scale

fischer Superbond dynamic

System description


Overview system components part 1;
cartridges / capsule / static mixer / injection adapter

Annex A 2

Overview system components Part 2


fischer anchor rod FIS A

Size: M12, M16




fischer anchor rod RG M




Size: M12, M16




Centering sleeve




fillable conical washer (various versions)




spherical washer




hexagonal nut with spherical contact surface




hexagon nut



lock nut



Filling adapter



Cleaning brush BS



Blow-out pump ABG or ABP with cleaning nozzle



Figures not to scale

fischer Superbond dynamic

System description





Overview system components part 2;
Steel components / filling adapter / cleaning brush / blow-out pump





Annex A 3

Table A4.1: Materials		
Part	Designation	Material
1	Injection cartridge	Mortar, hardener, filler
2	Resin capsule	Mortar, hardener, filler
3	fischer anchor rod FIS A or RG M	Property class 8.8; EN ISO 898-1:2013 zinc plated $\geq 5 \mu\text{m}$ EN ISO 4042:1999 A2K $f_{uk} \leq 1000 \text{ N/mm}^2$ $A_5 > 12\%$ fracture elongation
4	Centering sleeve	Plastic
5	Fillable conical washer similar to DIN 6319-G	zinc plated $\geq 5 \mu\text{m}$, EN ISO 4042:1999 A2K
6	Spherical washer	zinc plated $\geq 5 \mu\text{m}$, EN ISO 4042:1999 A2K
7	Hexagon nut	Property class 8; EN ISO 898-2:2012 zinc plated $\geq 5 \mu\text{m}$, ISO 4042:1999 A2K
7a	hexagonal nut with spherical contact surface	
8	Lock nut	zinc plated $\geq 5 \mu\text{m}$, EN ISO 4042:1999 A2K
fischer Superbond dynamic		Annex A 4
Product description Materials		

Specifications of intended use (part 1)

Table B1.1: Overview use and performance categories injection motar system

Anchorages subject to		FIS SB with				
		fischer anchor rod FIS A or fischer anchor rod RG M				
						
Hammer drilling with standard drill bit		Nominal drill bit diameter (d_0) 14 mm and 18 mm				
Hammer drilling with hollow drill bit (fischer "FHD", Heller "Duster Expert"; Bosch "Speed Clean"; Hilti "TE-CD, TE-YD")						
Diamond drilling		not permitted				
Fatigue load, in	<table border="0"> <tr> <td>uncracked concrete</td> <td rowspan="2">M12 and M16</td> </tr> <tr> <td>cracked concrete</td> </tr> </table>	uncracked concrete	M12 and M16	cracked concrete		
uncracked concrete	M12 and M16					
cracked concrete						
Design method I acc. to TR061	n = 1 to n = ∞					
Design method II acc. to TR061	n = ∞					
Use category I1 dry or wet concrete	M12 and M16					
Installation direction	D3 Downwards, horizontal and upwards (overhead) installation					
Installation method	prepositioned or push through installation					
Installation temperature	FIS SB: $T_{i,min} = -15\text{ °C}$ to $T_{i,max} = +40\text{ °C}$ FIS SB High Speed: $T_{i,min} = -20\text{ °C}$ to $T_{i,max} = +40\text{ °C}$					
In-service temperature	Temperature range I:	-40 °C to +40 °C	(max. short term temperature +40 °C; max. long term temperature +24 °C)			
	Temperature range II:	-40 °C to +80 °C	(max. short term temperature +80 °C; max. long term temperature +50 °C)			
fischer Superbond dynamic		Annex B 1				
Intended use Specifications injection motar system FIS SB (part 1)						

Specifications of intended use (part 2)	
Table B2.1: Overview use and performance categories resin capsule system	
Anchorage subject to	RSB with fischer anchor rod RG M 
Hammer drilling with standard drill bit 	Nominal drill bit diameter (d_0) 14 mm and 18 mm
Hammer drilling with hollow drill bit  (fischer "FHD", Heller "Duster Expert"; Bosch „Speed Clean“; Hilti "TE-CD, TE-YD")	
Diamond drilling 	Nominal drill bit diameter (d_0) 14 mm and 18 mm
Fatigue load, in uncracked concrete cracked concrete	M12 and M16
Design method I acc. to TR061	$n = 1$ to $n = \infty$
Design method II acc. to TR061	$n = \infty$
Use category I1 dry or wet concrete	M12 and M16
Installation direction	D3 Downward, horizontal and upwards (overhead) installation
Installation method	Only pre-positioned installation
Installation temperature	RSB: $T_{i,min} = -30\text{ °C}$ to $T_{i,max} = +40\text{ °C}$
In-service temperature	Temperature range I: -40 °C to +40 °C (max. short term temperature +40 C; max. long term temperature +24 C)
	Temperature range II: -40 °C to +80 °C (max. short term temperature +80 C; max. long term temperature +50 C)
fischer Superbond dynamic	
Intended use Specifications resin capsule system RSB (part 2)	
Annex B 2	

Specifications of intended use (part 3)

Base materials:

- Compacted reinforced or unreinforced normal weight concrete without fibers of strength classes C20/25 to C50/60 according to EN 206:2013+A1:2016

Use conditions (Environmental conditions):

- Structures subject to dry internal conditions (zinc coated steel).

Design:

- Anchorages have to be designed by a responsible engineer with experience of concrete anchor design.
- Verifiable calculation notes and drawings are to be prepared taking account of the loads to be anchored. The position of the anchor is indicated on the design drawings (e. g. position of the anchor relative to reinforcement or to supports, etc.).
- Anchorages have to be designed in accordance with:
 - EN 1992-4:2018 and
 - EOTA Technical Report TR 061 "Design method for fasteners in concrete under fatigue cyclic loading", Edition January 2013
- static and quasi static loading see ETA-12/0258
- Anchorages shall be positioned outside of critical regions (e.g. plastic hinges) of the concrete structure
- Fastenings in stand-off installation or with a grout layer are not covered by this European Technical Assessment (ETA)

Installation:

- Anchor installation is to be carried out by appropriately qualified personnel and under the supervision of the person responsible for technical matters of the site
- In case of aborted hole: The hole shall be filled with mortar
- Anchorage depth should be marked and adhered to on installation
- If only tension loads are involved in the application, the annular gap does not need to be filled

fischer Superbond dynamic


Intended use
Specifications (part 3)

Annex B 3

Table B4.1: Installation parameters for fischer anchor rods in combination with injection mortar system FIS SB


fischer anchor rods		Thread	M12	M16
Width across flats	SW	[mm]	19	24
Nominal drill hole diameter	d_0		14	18
Drill hole depth	h_0		$h_0 = h_{ef}$	
Effective embedment depth	$h_{ef, min}$		70	80
	$h_{ef, max}$		240	320
Minimum spacing and minimum edge distance	s_{min}		55	65
	c_{min}			
Diameter of the clearance hole of the fixture	prepositioned installation d_f		14-16	18-20
	push through installation d_f		15-16	19-20
Fixture thickness	$t_{fix, min}$		12	16
	$t_{fix, max}$			
Minimum thickness of concrete member	h_{min}		200	
Protrusion anchor rod FIS A	$h_{p, min}$		$h_{ef} + 30$ (≥ 100)	$h_{ef} + 2d_0$ (≥ 116)
Protrusion anchor rod RG M	$h_{p, min}$		$25 + t_{fix}$	$30 + t_{fix}$
Installation torque	T_{inst}	[Nm]	40	60

fischer anchor rod FIS A or RG M



Marking (on random place) fischer anchor rod:
Property class 8.8: • or colour coding

Installation conditions:



Installation conditions for RG M see Annex B 5

Figures not to scale

fischer Superbond dynamic

Intended use


Installation parameters fischer anchor rods FIS A and RG M in combination with injection mortar system FIS SB

Annex B 4

Table B5.1: Installation parameters for fischer anchor rods RG M in combination with resin capsule system RSB

fischer anchor rod RG M		Thread	M12	M16
Width across flats	SW	mm]	19	24
Nominal drill hole diameter	d_0		14	18
Drill hole depth	h_0		$h_0 = h_{ef}$	
Effective embedment depth	$h_{ef,1}$		75	95
	$h_{ef,2}$		110	125
	$h_{ef,3}$		150	190
Minimum spacing and minimum edge distance	$s_{min} = c_{min}$		55	65
Diameter of the clearance hole of the fixture	prepositioned installation d_f		14-16	18-20
Fixture thickness	$t_{fix,min}$		12	16
	$t_{fix,max}$		200	
Minimum thickness of concrete member	h_{min}	$h_{ef} + 30$ (≥ 100)	$h_{ef} + 2d_0$ (≥ 116)	
Protrusion anchor rod RG M	$h_{p,min}$	$32 + t_{fix}$	$38 + t_{fix}$	
Installation torque	T_{inst}	[Nm]	40	60


fischer Anchor rod RG M



Marking (on random place) fischer anchor rod RG M:

Property class 8.8: • or colour coding

Installation conditions:



Figures not to scale

fischer Superbond dynamic

Intended use

Installation parameters fischer anchor rod RG M in combination with resin capsule system RSB

Annex B 5

Table B6.1: Dimension of resin capsule RSB

Resin Capsule RSB		12 mini	12	16 mini	16
Capsule diameter	d_p	12,5		16,5	
Capsule length	L_p	72	97	72	95




Table B6.2: Assignment of resin capsule RSB to fischer anchor rod RG M

Anchor rod RG M		M12	M16
Effective anchorage depth	$h_{ef,1}$ [mm]	75	95
Related capsule RSB	[-]	12 mini	16 mini
Effective anchorage depth	$h_{ef,2}$ [mm]	110	125
Related capsule RSB	[-]	12	16
Effective anchorage depth	$h_{ef,3}$ [mm]	150	190
Related capsule RSB	[-]	2x 12 mini	2x 16 mini

Table B6.3: Parameters of the cleaning brush BS (steel brush with steel bristles)

The size of the cleaning brush refers to the drill hole diameter

Nominal drill hole diameter	d_0	14	18
Steel brush diameter	d_b	16	20



fischer Superbond dynamic

Intended use

Dimensions of the capsules; Assignment of the capsule to the anchor rod RG M;
Cleaning brush (steel brush)

Annex B 6

Maximum processing time of the mortar and minimum curing time

During the curing time of the mortar the concrete temperature may not fall below the listed minimum temperature. Minimal cartridge temperature +5 °C; minimal resin capsule temperature -15 °C

Table B7.1: FIS SB, RSB

Temperature at anchoring base [°C]	Maximum processing time t_{work}		Minimum curing time t_{cure}		
	FIS SB	FIS SB High Speed	FIS SB	FIS SB High Speed	RSB
-30 to -20	---	---	---	---	120 h
> -20 to -15	---	60 min	---	24 h	48 h
> -15 to -10	60 min	30 min	36 h	8 h	30 h
> -10 to -5	30 min	15 min	24 h	3 h	16 h
> -5 to ±0	20 min	10 min	8 h	2 h	10 h
> ±0 to +5	13 min	5 min	4 h	1 h	45 min
> +5 to +10	9 min	3 min	2 h	45 min	30 min
> +10 to +20	5 min	2 min	1 h	30 min	20 min
> +20 to +30	4 min	1 min	45 min	15 min	5 min
> +30 to +40	2 min	---	30 min	---	3 min





fischer Superbond dynamic

Intended use
Processing time and curing time

Annex B 7



Installation instructions part 1; injection mortar system FIS SB

Drilling and cleaning the hole (hammer drilling with standard drill bit)

1		<p>Drill the hole. Nominal drill hole diameter d_0 and drill hole depth h_0 see table B4.1</p>
2		<p>Clean the drill hole: Blow out the drill hole twice, with oil free compressed air ($p \geq 6$ bar) In uncracked concrete the use of the manual blow-out pump ABG is possible (Installation parameters: $d_0 < 18$ mm and $h_{ef} < 10d$)</p>
3		<p>Brush the drill hole twice. For deep holes use an extension. Corresponding brushes see table B6.3</p>
4		<p>Clean the drill hole: Blow out the drill hole twice, with oil free compressed air ($p \geq 6$ bar) In uncracked concrete the use of the manual blow-out pump ABG is possible (Installation parameters: $d_0 < 18$ mm and $h_{ef} < 10d$)</p>

Go to step 6 (Annex B 9)

Drilling and cleaning the hole (hammer drilling with hollow drill bit)

1		<p>Check a suitable hollow drill (see table B1.1) for correct operation of the dust extraction</p>
2		<p>Use a suitable dust extraction system, e. g. Bosch GAS 35 M AFC or a comparable dust extraction system with equivalent performance data. Drill the hole with hollow drill bit. The dust extraction system has to extract the drill dust nonstop during the drilling process and must be adjusted to maximum power. Nominal drill hole diameter d_0 and drill hole depth h_0 see table B4.1</p>

Go to step 6 (Annex B 9)






fischer Superbond dynamic

Intended use
Installation instructions part 1; injection mortar system FIS SB

Annex B 8

Installation instructions part 2; injection mortar system FIS SB

Preparing the cartridge

6		<p>Remove the sealing cap Screw on the static mixer (the spiral in the static mixer must be clearly visible)</p>
7		 <p>Place the cartridge into the dispenser</p>
8		 <p>Extrude approximately 10 cm of material out until the resin is evenly grey in colour. Do not use mortar that is not uniformly grey</p>

Go to step 9 (prepositioned installation Annex B 10 or push through installation Annex B11)






fischer Superbond dynamic

Intended use
Installation instructions part 2; injection mortar system FIS SB

Annex B 9

Installation instructions part 3, injection mortar system FIS SB

Prepositioned installation

9		<p>Fill approximately 2/3 of the drill hole with mortar. Always begin from the bottom of the hole and avoid bubbles. For drill hole depth ≥ 150 mm use an extension tube. For overhead installation, deep holes $h_0 > 250$ mm use an injection-adapter.</p>
10		<p>Only use clean and oil-free anchor elements. Mark the setting depth of the anchor. Push the fischer anchor rod down to the bottom of the hole, turning it slightly while doing so.</p> <p>After inserting the anchor element, excess mortar must be emerged around the anchor element. If not, pull out the anchor element immediately and reinject mortar.</p> <p>For overhead installations support the anchor rod with wedges. (e. g. fischer centering wedges)</p>
11		<p>Wait for the specified curing time t_{cure} see table B7.1</p>
12		<p>Attach the component and install the washer and nuts - without centering sleeve. Tighten the hexagon nut with installation torque T_{inst} (see table B4.1) Tighten lock nut manually, then use wrench to give another quarter or half turn.</p>
13		<p>After the minimum curing time is reached, the gap between anchor and fixture (annular clearance) has to be filled with mortar (FIS SB or FIS SB High Speed) via the fillable conical washer. If only tension loads are involved in the application, the annular gap does not necessarily have to be filled.</p>

fischer Superbond dynamic





Intended use

Installation instructions part 3; prepositioned installation; injection mortar system FIS SB

Annex B 10

Installation instructions part 4, injection mortar system FIS SB

Push through installation

9		<p>Fill approximately 2/3 of the drill hole incl. fixture with mortar. Always begin from the bottom of the hole and avoid bubbles. For drill hole depth ≥ 150 mm use an extension tube. For overhead installation, deep holes $h_0 > 250$ mm use an injection-adapter.</p>
10		<p>Only use clean and oil-free anchor elements. Mark the setting depth of the anchor. Push the Fischer anchor rod down to the bottom of the hole, turning it slightly while doing so.</p> <p>After inserting the anchor element with pre-assembled components, excess mortar must be emerged around the anchor element (minimum on one point of the fillable conical washer). If not, pull out the anchor element immediately and reinject mortar.</p>
11		<p>Wait for the specified curing time t_{cure} see table B7.1</p>
12		<p>Tighten the hexagon nut with installation torque T_{inst} see table B4.1. Tighten lock nut manually, then use wrench to give another quarter or half turn.</p>

fischer Superbond dynamic



Intended use

Installation instructions part 4; push through installation; injection mortar system FIS SB

Annex B 11



Installation instructions part 5; resin capsule RSB

Drilling and cleaning the hole (hammer drilling with standard drill bit)

1		<p>Drill the hole. Nominal drill hole diameter d_0 and drill hole depth h_0 see table B5.1</p>
2		<p>Clean the drill hole: Blow out the drill hole four times, with oil free compressed air ($p \geq 6$ bar) In uncracked concrete the use of the manual blow-out pump ABG is possible (Installation parameters: $d_0 < 18$ mm and $h_{ef} < 10d$)</p>

Go to step 6 (Annex B 14)

Drilling and cleaning the hole (hammer drilling with hollow drill bit)

1		<p>Check a suitable hollow drill (see table B2.1) for correct operation of the dust extraction</p>
2		<p>Use a suitable dust extraction system, e. g. Bosch GAS 35 M AFC or a comparable dust extraction system with equivalent performance data.</p> <p>Drill the hole with hollow drill bit. The dust extraction system has to extract the drill dust nonstop during the drilling process and must be adjusted to maximum power. Nominal drill hole diameter d_0 and drill hole depth h_0 see table B5.1</p>

Go to step 6 (Annex B 14)







fischer Superbond dynamic

Intended use
Installation instructions part 5; resin capsule RSB

Annex B 12

Installation instructions part 6; resin capsule RSB

Drilling and cleaning the hole (wet drilling with diamond drill bit)

1		<p>Drill the hole. Drill hole diameter d_0 and nominal drill hole depth h_0 see table B5.1</p>		<p>Break the drill core and remove it</p>
2		<p>Flush the drill hole, until clear water emerges from the drill hole</p>		
3		<p>Blow out the drill hole twice, using oil-free compressed air ($p > 6$ bar)</p>		
4		<p>Brush the drill hole twice using a power drill. Corresponding brushes see table B6.3</p>		
5		<p>Blow out the drill hole twice, using oil-free compressed air ($p > 6$ bar)</p>		

Go to step 6 (Annex B 14)








fischer Superbond dynamic

Intended use
Installation instructions part 6; resin capsule RSB

Annex B 13

Installation instructions part 7; resin capsule RSB

Installation fischer anchor rod RG M

6		<p>Resin capsule RSB or two RSB mini, must be pushed into the drill hole by hand</p>	 <p>Depending on the anchor being installed, use a suitable setting tool</p>
7		<p>Only use clean and grease-free anchors. Using a suitable adapter, drive the fischer anchor rod RG M into the capsule using a hammer drill set on rotary hammer action. Stop when the anchor reaches the bottom of the hole and is set to the correct embedment depth</p>	
8		<p>When reaching the correct embedment depth, excess mortar must emerge from the mouth of the drill hole. If not, the anchor must be pulled out directly and another resin capsule must be pushed into the drill hole. Setting process must be repeated (Step 7)</p>	
9		<p>Wait for the specified curing time t_{cure} see table B7.1</p>	
10		<p>Attach the component and install the washer and nuts - without centering sleeve. Tighten the hexagon nut with installation torque T_{inst} (see table B5.1). Tighten lock nut manually, then use wrench to give another quarter or half turn.</p>	
11		<p>Fill the gap between anchor and fixture (annular clearance) with mortar (FIS SB or FIS SB High Speed) via fillable conical washer. If only tension loads are involved in the application, the annular gap does not necessarily have to be filled.</p>	

fischer Superbond dynamic

Intended use

Installation instructions part 7; prepositioned installation; resin capsule RSB

Annex B 14

Table C1.1: Essential characteristics under tension fatigue load for FIS SB / RSB; Design method I according to TR 061					
Required evidence					
		Number of load cycles (n)			
		$n \leq 10^4$	$10^4 < n \leq 5 \cdot 10^6$	$5 \cdot 10^6 < n \leq 10^8$	$n > 10^8$
Tension load capacity					
Characteristic steel fatigue resistance					
$\Delta N_{Rk,s,0,n}$	[kN]	$0,75 \cdot N_{Rk,s,(8.8)} \cdot 0,33$	$0,75 \cdot N_{Rk,s,(8.8)} \cdot 10^{(-0,12 \cdot \log(n))}$	$0,75 \cdot N_{Rk,s,(8.8)} \cdot 10^{(-0,438 - 0,057 \cdot \log(n))}$	$0,75 \cdot N_{Rk,s,(8.8)} \cdot 0,12$
Characteristic combined pull- out /concrete cone fatigue resistance in uncracked and cracked concrete					
Characteristic bond strength in uncracked concrete					
$\Delta \tau_{Rk,p,ucr,0,n}$	[N/mm ²]	$\tau_{Rk,ucr} \cdot 0,575$	$\tau_{Rk,ucr} \cdot 10^{(-0,06 \cdot \log(n))}$	$\tau_{Rk,ucr} \cdot 10^{(-0,207 - 0,029 \cdot \log(n))}$	$\tau_{Rk,ucr} \cdot 0,35$
Characteristic bond strength in cracked concrete					
$\Delta \tau_{Rk,p,cr,0,n}$	[N/mm ²]	$\tau_{Rk,cr} \cdot 0,575$	$\tau_{Rk,cr} \cdot 10^{(-0,06 \cdot \log(n))}$	$\tau_{Rk,cr} \cdot 10^{(-0,207 - 0,029 \cdot \log(n))}$	$\tau_{Rk,cr} \cdot 0,35$
Characteristic fatigue resistance for concrete cone and concrete splitting					
Characteristic concrete fatigue resistance in uncracked concrete					
$\Delta N_{Rk,c/sp,ucr,0,n}$	[kN]	$N_{Rk,c/sp,ucr} \cdot 0,66$	$N_{Rk,c/sp,ucr} \cdot 1,1 \cdot n^{-0,055} \geq 0,5$	$N_{Rk,c/sp,ucr} \cdot 0,50$	
Characteristic concrete fatigue resistance in cracked concrete					
$\Delta N_{Rk,c/sp,cr,0,n}$	[kN]	$N_{Rk,c/sp,cr} \cdot 0,66$	$N_{Rk,c/sp,cr} \cdot 1,1 \cdot n^{-0,055} \geq 0,5$	$N_{Rk,c/sp,cr} \cdot 0,50$	
Exponents and load-transfer factor					
Exponent for combined load					
$\alpha_s = \alpha_{sn}$	[-]	0,5			
Load-transfer under					
ψ_{FN}	[-]	0,5			
$N_{Rk,s,(8.8)}$, $\tau_{Rk,ucr}$, $\tau_{Rk,cr}$ see ETA-12/0258 $N_{Rk,c/sp,ucr}$, $N_{Rk,c/sp,cr}$ see ETA-12/0258 and EN 1992-4:2018					
fischer Superbond dynamic				Annex C 1	
Performance Essential characteristic under tension fatigue load; Design method I according to TR 061					

Table C2.1: Essential characteristic under shear fatigue load for FIS SB / RSB; Design method I according to TR 061					
Required evidence					
		Number of load cycles (n)			
		$n \leq 10^4$	$10^4 < n \leq 5 \cdot 10^6$	$5 \cdot 10^6 < n \leq 10^8$	$n > 10^8$
Shear load capacity					
Characteristic steel fatigue resistance					
$\Delta V_{Rk,s,0,n}$	[kN]	$V_{Rk,s,(8.8)} \cdot 0,23$	$V_{Rk,s,(8.8)} \cdot 10^{(-0,197 \cdot \log(n))}$	$V_{Rk,s,(8.8)} \cdot 10^{(-0,575 - 0,068 \cdot \log(n))}$	$V_{Rk,s,(8.8)} \cdot 0,08$
Characteristic concrete pry out fatigue resistance in cracked and uncracked concrete					
$\Delta V_{Rk,cp,0,n}$	[kN]	$V_{Rk,cp} \cdot 0,574$	$V_{Rk,cp} \cdot 1,2 \cdot n^{-0,08} \geq 0,5$		$V_{Rk,cp} \cdot 0,5$
Characteristic concrete edge fatigue resistance in cracked and uncracked concrete					
$\Delta V_{Rk,c,0,n}$	[kN]	$V_{Rk,c} \cdot 0,574$	$V_{Rk,c} \cdot 1,2 \cdot n^{-0,08} \geq 0,5$		$V_{Rk,c} \cdot 0,5$
Exponents, load-transfer factor					
Exponent for combined tension and shear loading, steel failure					
$\alpha_s = \alpha_{sn}$	[-]				0,5
Exponent for combined tension and shear verification regarding failure modes other than steel failure					
α_c	[-]				1,5
Load-transfer factor					
Ψ_{FV}	[-]				0,5
$V_{Rk,s,(8.8)}$ see ETA-12/0258 $V_{Rk,c}, V_{Rk,cp}$ see ETA-12/0258 and EN 1992-4:2018					
fischer Superbond dynamic					Annex C 2
Performance Essential characteristic under shear fatigue load; Design method I according to TR 061					

Table C3.1: Essential characteristics under tension and shear fatigue load; Design method II according to TR061					
Size		M 12		M 16	
Tension load					
Effective embedment depth	$h_{ef,min}$	[mm]	95		125
Steel failure					
Characteristic steel fatigue resistance	$\Delta N_{RK,s,0,\infty}$	[kN]	6,1		11,3
Exponent for combined tension and shear loading	$\alpha_s = \alpha_{sn}$	[-]	0,5		
Characteristic combined pull- out /concrete cone fatigue resistance in uncracked and cracked concrete					
Characteristic bond resistance	$\Delta \tau_{RK,p,ucr,0,\infty}$	[N/mm ²]	$\tau_{RK,ucr} \cdot 0,35$		
	$\Delta \tau_{RK,p,cr,0,\infty}$	[N/mm ²]	$\tau_{RK,cr} \cdot 0,35$		
Concrete failure					
Characteristic concrete fatigue resistance	$\Delta N_{RK,c,0,\infty}$	[-]	$0,5 \cdot N_{RK,c}$ ¹⁾		
	$\Delta N_{RK,sp,0,\infty}$	[-]	$0,5 \cdot N_{RK,sp}$ ¹⁾		
Exponent for combined tension and shear verification	α_c	[-]	1,5		
Load-transfer factor	Ψ_{FN}	[-]	0,5		
Shear load					
Steel failure					
Characteristic steel fatigue resistance	$\Delta V_{RK,s,0,\infty}$	[kN]	2,7		5,0
Exponent for combined tension and shear loading	$\alpha_s = \alpha_{sn}$		0,5		
Concrete pryout failure					
Characteristic concrete fatigue resistance	$\Delta V_{RK,cp,0,\infty}$	[kN]	$0,5 \cdot V_{RK,cp}$ ¹⁾		
Concrete edge failure					
Characteristic concrete fatigue resistance	$\Delta V_{RK,c,0,\infty}$	[kN]	$0,5 \cdot V_{RK,c}$ ¹⁾		
The value of h_{ef} ($=l_f$) under shear load	l_f	[mm]	≥ 95		≥ 125
Effective outside diameter of the anchor	d_{nom}	[mm]	12		16
Exponent for combined tension and shear verification	α_c		1,5		
Load-transfer factor	Ψ_{FV}	[-]	0,5		
¹⁾ $N_{RK,c}$, $N_{RK,sp}$, $V_{RK,c}$ and $V_{RK,cp}$ – Essential characteristics for concrete failure under static and quasi static load according to ETA-12/0258 and EN 1992-4:2018.					
fischer Superbond dynamic					Annex C 3
Performance Essential characteristics under tension / shear fatigue load; Design method II according to TR 061					